


GATEKEEPER

MOBILE VIDEO SOLUTIONS FOR BUILDING SAFER & SMARTER COMMUNITIES



Intelligent Temperature Sensing System Pedestal Mount Installation Guide

Document Ref. No. : DN3329

Version No. : 1.0.2

Document Date : October 2020

1 INTRODUCTION..... 3

1.1 WELCOME TO YOUR NEW INTELLIGENT TEMPERATURE SENSING SYSTEM.....3

2 ITSS PEDESTAL MOUNT INSTALLATION 4

2.1 PEDESTAL MOUNT4

 2.1.1 *Assembly of Pedestal Mount* 4

2.2 WIRING PROCEDURE7

2.3 INSTALLATION REQUIREMENTS.....8

3 CUSTOMER LIMITED WARRANTY 9

4 CONTACT INFORMATION..... 10

1 Introduction

1.1 Welcome to Your New Intelligent Temperature Sensing System

Congratulations on the purchase of your new Gatekeeper Systems Intelligent Temperature Sensing System (ITSS).

Gatekeeper's Health Monitoring Panel is a standalone Intelligent Temperature Sensing System that detects temperature. Artificial Intelligence is used to detect the presence of a face. A thermal sensor is used to calculate the individual's temperature.

This superior design prevents people from attempting to get temperature measurements from their hands or other objects that may be colder. The use of Artificial Intelligence provides rapid temperature sensing with laser precision. The Panel is compact and easy to install. The site administrators have immediate access to information they need to keep everyone safe.

2 ITSS Pedestal Mount Installation

This section provides instructions on the installation and setup of ITSS on a pedestal mount at a mobile or fixed-site location.

2.1 Pedestal Mount

The panel can be mounted on the pedestal on an angle that captures people standing up to 2 meters away from the panel. The panel can be mounted on a vehicle or at a fixed site.

2.1.1 Assembly of Pedestal Mount

- 1) Remove the pole mount bracket assembly from the back of the Temperature Panel.
- 2) Remove the 4 hex screws from the mount assembly. Set aside screws




Fig 1 (a) Pole Mount Bracket (b) Mounting Plate

- 3) Attach the U bracket to the panel and then attach the ball mount to the U bracket. They will only go on in one direction.




Fig 2 (a) U Bracket (b) Ball Mount

- 4) Use the 4 self-tapping screws (provided) to mount the pedestal base to the wall/ console/ dash. The pole can be removed prior to mounting if that makes it easier. Just loosen the knob enough to get the pole out.



Fig 3. Base with knob on the panel

- 5) After the base is securely mounted, attach the panel to the mount. Tighten down both knobs to make sure the panel will not move.
- 6) For a more secure install, use the set screws (provided) instead of the knobs.

2.2 Wiring Procedure




Fig 4 Cable Diagram - Power Connector on CAB000496 only, CAB000495 has flying leads

If mounting in a vehicle, the panel will come with CAB000495 and have flying leads for the power, ground and ignition. Connect the 3 cables to the vehicle and then plug the connector into the Temperature Panel. The panel will start when ignition is turned on and be ready within 30 seconds.

If mounting in a fixed site location, it will come with CAB000496 and a wall power supply. CAB000496 has a 3.5mm barrel jack for the power. Plug the cable into the back of the Temperature Panel and then connect the barrel jack to the power supply. Plug the power supply into a standard wall outlet, using an extension cord if required. The panel will automatically power on and be ready within 30 seconds.

All wires should be neatly tied to the pole using cable ties. Snip off excess cable tie ends

Refer to ITSS user guide or reach out to our technical support for any further information you may require.

2.3 Installation Requirements

As part of installation best practices, it is recommended to mount the device in the vehicle cabin area (mobile) or at a fixed-site where there is environmental control (i.e. heating and/or air-conditioning). This will extend the device operating life by not exposing it unnecessarily to adverse environmental conditions.

Keep the following in mind so that the customer warranty is not voided.:

- Do not put excess tension on the power cable.
- Allow the panel to boot up this will take about 20 seconds.
- The Temperature Panel comes fully configured.

Refer to the manual for any further information you may require.



The device has an operating temperature range of 0°C - 50°C (32°F to 122°F). Please ensure that the device is mounted in an area in which acceptable temperature ranges are experienced.



To ensure the Customer Warranty is not voided do not disassemble the unit and refer to wiring diagram for correct connections.

3 Customer Limited Warranty

GATEKEEPER SYSTEMS INC. warrants that any product manufactured or supplied by Gatekeeper Systems Inc and found in the reasonable judgment of Gatekeeper Systems Inc to be defective in material or workmanship will be repaired or replaced by Gatekeeper Systems Inc without charge for parts and labor.

This warranty shall cover the following periods and Gatekeeper equipment:

- Interior Cameras - 5 Years
- Exterior Cameras - 1 Year
- G series DVR's – 3 Years
- Gatekeeper Branded SD Cards – 3 Years
- Hard Drives & SSD – 1 Year
- 360° Surround Vision Camera System – 1 Year
- ITSS – Health Monitoring Panel – 1 Year

All Accessories and Other Products Not Identified above - 1 Year

The warranty periods commence on the date of shipment. During the period of the warranty the Company, at its discretion will repair and/or replace all improperly functioning equipment caused by a manufacturing defect. This warranty does not protect against accidental or intentional damage, vehicle electrical systems generating steady state or transients, voltages or currents exceeding product specification, loss, acts of nature, water damage, or any other event that did not originate during the manufacturer of the product.

The Gatekeeper Systems product including any defective part must be returned to Gatekeeper Systems within the warranty period. The expense of delivering Company product to Gatekeeper Systems for warranty work will be paid by the customer. The expense of delivering Company product back to the customer will be paid by Gatekeeper Systems. Gatekeeper Systems' responsibility in respect to claims is limited to making the required repairs or replacements and no claim of breach of warranty shall be cause for cancellation or rescission of the contract of sale. Proof of purchase complete with the serial numbers of the products purchased will be required by the customer to substantiate any warranty claim. All warranty work must be performed by an authorized Gatekeeper Systems service representative.

This warranty does not cover any Gatekeeper Systems' product that has been subject to misuse, neglect, negligence, or accident, or that has been operated in any way contrary to the operating instructions as specified by Gatekeeper Systems either verbally, in writing, by instructions written on the product or in the Gatekeeper Systems Installation and Operating Manual. This warranty does not apply to any damage to the Gatekeeper Systems product that is the result of improper maintenance or to any Gatekeeper Systems' product that has been altered or modified so as to adversely affect the products' operation, performance or durability or that has been altered or modified so as to change its intended use.

Gatekeeper Systems Inc is not responsible for lost or missing video.

The warranty does not extend to repairs made necessary by normal wear or by the use of parts or accessories which are either incompatible with the Company product or adversely affect its operation, performance or durability.

Gatekeeper Systems reserves the right to change or improve the design of any Company product without assuming any obligation to modify any product previously manufactured.

ALL IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE SPECIFIED PERIOD FOR EACH PRODUCT CATEGORY AS LISTED IN THIS DOCUMENT. ACCORDINGLY, ANY SUCH IMPLIED WARRANTIES INCLUDING MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE, ARE DISCLAIMED IN THEIR ENTIRETY AFTER THE EXPIRATION OF THE APPROPRIATE WARRANTY PERIOD. GATEKEEPER SYSTEMS' OBLIGATION UNDER THIS WARRANTY IS STRICTLY AND EXCLUSIVELY LIMITED TO THE REPAIR OR REPLACEMENT OF DEFECTIVE PARTS, AND GATEKEEPER SYSTEMS INC. DOES NOT ASSUME OR AUTHORIZE ANYONE TO ASSUME FOR THEM ANY OTHER OBLIGATION.

GATEKEEPER SYSTEMS INC ASSUMES NO RESPONSIBILITY FOR INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES INCLUDING, BUT NOT LIMITED TO THE EXPENSE OF RETURNING THE COMPANY PRODUCT TO GATEKEEPER SYSTEMS INC. CORPORATE HEAD OFFICE, MECHANIC'S TRAVEL TIME, CUSTOMER LABOR EXPENSES, TELEPHONE OR TELEGRAM CHARGES, RENTAL OF LIKE PRODUCT DURING THE TIME WARRANTY SERVICE IS BEING PERFORMED TRAVEL, LOSS OF USE OF THE PRODUCT, LOSS OF TIME OR INCONVENIENCE.

WARRANTY SERVICE

To obtain warranty service, the purchaser must notify the Company during the warranty period. The Purchaser will discuss the defect or problem with a Company technician, and once the problem has been verified the Company will issue a return material authorization number (RMA) authorizing the purchaser to return faulty merchandise to the Company for repair or replacement as determined by the Company. It may be necessary for the customer to assist Gatekeeper Systems in assessing failed product. Gatekeeper Systems may require the customer to remove hardware, manipulate software and/or perform other diagnostic activities. Failure to assist in and allow remote diagnostic activities may result in a service fee being charged.

Advance replacements will be issued for the first 90 days from the date of shipment.

This Warranty applies to all Company products manufactured by Gatekeeper Systems and sold in the United States and Canada.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

CANADA OPERATIONS:
 Gatekeeper Systems Inc.
 301-3 1127 Wheel Avenue
 Abbotsford BC V2T 6H1
 Tel. 1.604.864.6187
 Fax. 1.604.864.8490
 Toll Free (N.A.) 1.888.666.4833

4 Contact Information

GATEKEEPER SYSTEMS INC.

301-31127 Wheel Avenue

Abbotsford BC V2T 6H1

Tel - 1 604 864 6187

Fax - 1 604 864 8490

Toll Free - 1 888 666 4833

GATEKEEPER SYSTEMS USA INC.

7-200 Rittenhouse Circle

Bristol, PA 19007

Tel - 1 604 864 6187

Fax - 1 604 864 8490

Toll Free - 1 888 666 4833

SALES & TECHNICAL SUPPORT

For technical support, contact Gatekeeper's Customer Care Group at Toll Free (N.A.) 1-888-666-4833 or email customercare@gatekeeper-systems.com

Gatekeeper also provides additional online training and support tools at: <https://www.gatekeeper-systems.com/support/>