



**MAPPING A COMRAD™ DRIVE.**

If when you connect your Comrad™ to your PC and it is not listed when you double click on my computer (Fig 1), or the Pop-Up window asking you to run the program doesn't appear, it may be due to a conflict with a network drive or another USB device. If this is the case, follow these steps:




FIG 1

Single Right click on My Computer, (Fig 2). This will bring up an Options Menu. Single Left click on Manage.



FIG 2

This will bring up the window shown in Fig 3. Single Left click on Disk Management, located under STORAGE.




FIG 3

You will now be presented with a listing of drives, you may need to scroll to see them all. Single Left click on the drive, (in this example P:). Your setup will differ from this example. Highlight the drive letter and Single Right click on the drive and an options menu will appear. Choose Change Drive Letter and Paths, Fig 4.




FIG 4

Another smaller window, (Fig 5), will now open, click the Change Button.




FIG 5

From the window which appears, Fig 6, choose a drive letter that has not yet been allocated, in this example R:, then click OK.




FIG 6




FIG 7

Once done, if you now double click My Computer, you will see your Comrad™ listed in the available drives, Fig 7.

**Protecting Your Precious Cargo**

